International Letters of Chemistry, Physics and Astronomy

Calcium Carbonate Scale Formation, Prediction and Treatment (Case Study Gumry Oilfield-PDOC)

A. Saifelnasr¹, M. Bakheit¹, K. Kamal^{2,*}, A. Lila³

¹College of Science, Nelain University, Sudan
 ²College of Science, Bahri, University, Sudan
 ³Central Petroleum Laboratory, Sudan
 *E-mail address: kamaltha99@rediffmail.com

ABSTRACT

In this study the predictions and probabilities of calcium carbonate scale formation and corrosion occurrence inside Gumry Field Process Facilities (GFPF) and produced water injection process units (PWTP) was carried out. This was done calculating the Langelier Saturation Index (LSI), Ryznar Stability Index (RSI), Puckorius Scaling Index (PSI). The samples results for LSI index and PSI index were compared and found that all samples under threaten of calcium carbonate scale. The samples results for RSI index and found that all samples under formation of heavy calcium carbonate scale. Special excel computer program was designed to calculate the (LSI, RSI, PSI). The scale was cleaned and removed by 10 % diluted hydrochloric acid and commercial scale inhibitor.

Keywords: scale formation, LSI, RSI, PSI indices.

1. INTRODUCTION

The production of water is natural consequence of the production of oil and gas from subterranean reservoirs. Water that is present in these reservoirs contains dissolved salts and dissolved gases. Under certain conditions these salts precipitate and become Scale deposits [1]. It is not possible to produce oil and gas for any significant time before water is also produced .The water /oil boundary will rise over time and channeling from water permeable zones will cause increased water to be produced. Scales are formed due to precipitation and crystal growth at the water surface. Precipitation is due to low solubility or excess amounts of salts. The scale forming salt in heat exchangers and boilers are those having retrograde solubility with temperature [2].

The scale formation and corrosivity is qualitatively predicted using various indices [3,4] that depend upon water parameters. The Langelier Saturation Index (LSI) [5] is an indicator of cooling water scale potential. This index indicates the driving force for scale formation and

growth in terms of pH as a master variable. It is calculated the value of alkalinity (mg L^{-1} as CaCO₃ or calcite), the calcium hardness (mg L^{-1} Ca²⁺ as CaCO₃), the total dissolved solids (mg L^{-1} TDS), the actual pH, and the temperature of the water (°C).

 $LSI = pH - pH_s$,

where pH is the actual pH and pH_s is the saturation pH.

The pH_s can be calculated from the relation, $pH_s = (9.30 + A + B) - (C + D)$, where

$$A = \frac{(\log[TDS] - 1)}{10},$$

$$B = -13.12x \log(°C + 273) + 34.55,$$

$$C = \log[Ca^{+2}asCaCO_3] - 0.4,$$

$$D = \log[alkaalinityasCaCO_3]$$

Thus a negative LSI indicates no potential to scale, the water will dissolve CaCO₃, while a positive value indicates CaCO₃ precipitation. Ryznar Stability Index (RSI) [6] is given by: RSI = 2 pH_s - pH, whereas RSI > 6 indicates corrosion while RSI < 6 indicates scale formation. Puckorius Scaling Index (PSI) [7] is obtained from the relation: PSI = 2 pH_s - pH_e, whre pH_{eq} = 1.465 x log₁₀ [Alkalinity] + 4.54 and [Alkalinity] = [HCO₃⁻] + 2 [CO₃²⁻] + [OH⁻]. It has the same indication as RSI.

Scale and corrosion continue to be serious and costly problems in gas and oil wells and production facilities. Scale commonly occurs in multiple locations within a production system. These locations include production and injection wells, flow lines, valves, vessels, separators, heat exchangers and pumps.

The result of scale deposition in oil and gas production systems is increased costs owing to equipment failures, manpower-related maintenance of scaled equipment, and lost production. Scale formation increases when active sites are there due to the a direct crystal growth without crystal formation. "*Scale inhibitors don't prevent precipitation, they delay the inevitable by extending induction time.*" [8,9]

Equation Time = _______ [inhibitor] M k [SR - 1] P-1

where Time is the induction time
inhibitor is the scale inhibitor molar concentration
M is s coefficient
k is a temperature dependent rate constant
SR is the saturation ratio
P is the number of molecules in a critical sized cluster

Dosage models have been used successfully to prevent scale in cooling systems, reverse osmosis, oil field and mining applications.

The impact of common scale inhibitors on induction time can be modeled by adding an inhibitor term to a classic model for induction time [10,11]

It must be noted that there is a maximum saturation level beyond which inhibitors will not prevent scale by this mechanism at any dosage. This is typically 150 x saturation for calcite.

The calcium carbonate depositions in Produced Water Package Treatment (PWPT) used for injection purpose and pH, temperature, total suspending solids (TSS), Total Dissolve Solids (TDS),), Alkalinity, Calcium Hardness, conductivity were determined and the indices, LSI, RSI and PSI were calculated using excel program.

2. MATERIALS & METHODS

Analar grade chemicals were used as received. Twenty four untreated raw produced water was collected from the sample point at Gumry FPF, Sudan, on 25th -June-2009 and same in25th of January 2010 at 9:00AM.

Temperature was determined using probe (model testo 915-1, pH with pH meter (Wagtech UK), TDS, turbidity, conductivity were determined using Hanna instruments. Total hardness and calcium were determined by EDTA titration. Alkalinity was obtained by titration against standard sulfuric acid.

3. RESULTS & DISCUSSION

The Physicochemical properties for Gumry produced water is given in Table A.

Test	Test						
рН		6.37					
Turbidity	Turbidity						
Total Suspending	4.00	ppm					
Total Dissolved	d Salts	3330	ppm				
Alkalinity	/	4630.05	ppm				
Conductivi	ty	6320	µs/cm				
Hardness	total	57.80	ppm				
	temporary	48.60	ppm				

Fable A. Gumry produced w	ter package treatment P	WT outlet results.
---------------------------	-------------------------	--------------------

The indices LSI, RSI and PSI are calculated using the data of Table 1. According to the results of (OGMs) in Table 1 for samples collected in the year 2009 and Table 2 for samples collected in the year 2010, (Langelier Saturation Index) LSI prediction that all samples under slight calcium carbonate (CaCO₃) scale forming conditions. In the Table 1 Oil Gathering Manifold 2 (OGM-2), shows negative LSI reading (-0.04) which indicate of (slightly corrosive but non scale forming), changed to (+0.34) in Table 2 year 2010 which means (slightly scale forming and corrosive).

LSI Index	2.0	0.5	0.02	-0.5	-2.0
Value Indication	Scale forming but non corrosive	Slightly scale forming and corrosive	Balanced but pitting corrosion possible	Slightly corrosive but non-scale forming	Serious corrosion

Interpretation of the Langelier Saturation Index (Carrier, 1965) [12]

The Ryznar Stability index (RSI) predict that all samples collected in the s 2009 and 2010 were under threat of (heavy calcium carbonate (CaCO₃) scale forming). All the samples RSI changed from the range (5to 6) which means and predict (light scale) in the year 2009 to the range RSI (4 to 5) in the year 2010 which indicates and predicts (heavy scale) and expect more complicated problem of scale buildup in the coming years if no real treatments or chemical additives are used.

Risk of emergency shutdown for long time will reduce pressure, release soluble acid gases, and increase pH; all these factors activate calcium carbonate scale to form and the system will face serious problems in the next staring.

RSI Value	4.0 - 5.0	5.0 - 6.0	6.0 - 7.0	7.0 - 7.5	7.5 - 9.0	> 9.0
Indication	Heavy scale	Light scale	little scale or corrosion	Corrosion significant	Heavy corrosion	Corrosion intolerable

Interpretation of the Ryznar Stability Index (Carrier, 1965)

The PSI values also predicts that all samples witch collected in the year 2009 and 2010 were under heavy calcium carbonate ($CaCO_3$) scale formation.

So that all prediction factors (LSI, RSI, PSI) clear that the Gumry plant, oil productive Wells, produced water treatment system, Crude-Crude heaters, Export Tanks and heat Exchangers under threaten of heavy calcium carbonate scale forming.

The presence of high concentration of carbon dioxide (CO_2) will sustainable the system without Scale for long time due to reduction in water PH and also the presence of high pressure in the system.

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS mg/l	Conductivity µs	PHs	Hd	ISI	RSI	ISA
OGM-2	66.7	686	2500	30	2590	5240	6.41	6.35	-0.04	6.46	3.3
OGM-3	59.1	687	2700	40	2570	5120	6.209	6.32	+0.11	6.09	2.9
OGM-4	81.6	689	5000	46	2725	8890	6.67	6.8	+1.12	4.55	1.4
OGM-5	82.1	685	5100	45	4200	8500	5.69	6.46	+0.76	4.93	1.4
FPF INLET	74	638	4800	45	3930	7840	5.8	6.5	+0.65	5.19	1.76

Table 1. Gumry Oil Gathering Manifolds (OGM) (2009).

 Table 2. Gumry Oil Gathering Manifolds (OGM) (2010).

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ³ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Mg/I	Conductivity µs	PHs	Hd	ISI	RSI	ISd
OGM-2	68.1	672	3000	66	3640	7280	6.00	6.32	+0.34	5.63	2.23
OGM-3	67.8	675	2500	66.6	3420	6809	6.05	6.23	+0.17	5.88	2.66
OGM-4	83.9	672	3250	66.6	5740	11470	5.7	6.75	+1.04	4.65	1.72
OGM-5	80.5	671	4500	65.5	5650	11310	5.6	6.45	+0.88	4.79	1.35
FPF INLET	75	640	5750	74.5	5580	11170	5.55	6.5	+0.95	4.59	1.05

In Table 3 and Table 4 first and second stage separators the factors (LSI, RSI and PSI) predict the risk of scale which may buildup in the water outlet inside Separators will cause reduction in the pipe diameter, that cause to the bad water separations and prolong separation time.

Thermodynamic considerations (pressure drop) activate scale forming and buildup, temperature increased in the second stage separators, heat exchangers so that increasing temperature will increase scale tendency in the mentioned facilities and will be under threaten of scale forming.

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO3 mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Mg/I	Conductivity µs	PHs	Hd	ISI	RSI	ISA
1 ST A	74	535	4700	50	3825	7650	5.8	6.51	+0.69	5.12	1.7
1 ST B	74	533	4800	60	3740	7490	5.7	6.4	+0.68	5.04	1.51
1 ST C	74	533	4700	100	3750	7500	5.5	6.5	+0.99	4.5	1.09
1 ST D	74	534	4700	55	3730	7530	5.75	6.5	+0.7	5.03	1.61
2 ND A	81	270	4500	25	3800	7600	6.01	6.2	+0.19	5.8	2.14
2 ND B	82	274	4600	25	3650	7300	5.98	6.2	+0.21	5.77	2.07
2 ND C	82	274	4800	30	3740	7720	5.88	6.15	+0.26	5.62	1.85
2 ND D	81	280	4600	35	3680	7120	5.85	6.25	+0.39	5.46	1.81

Table 3. Gumry FPF first and second stage Separators Samples (2009).

FPF=Field Process Facilities

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS mg/l	Conductivity µs	PHs	Hd	ISI	RSI	ISA
1 st A	75.1	535	5700	74	5580	11170	5.55	6.5	+0.94	4.6	1.06
1 ST B	75.3	531	5450	74.5	5650	11240	5.566	6.36	+0.79	4.77	1.12
1 st C	75.1	531	5700	74.3	5560	11200	5.55	6.41	+0.86	4.69	1.06
1 st D	75.3	527	5700	74.5	5700	11630	5.54	6.46	+0.91	4.63	1.05
2 nd A	81.5	291	5550	74.5	5570	11140	5.45	6.26	+0.79	4.66	0.89
2 nd B	81.5	289	5500	74.5	5590	11170	5.46	6.19	+0.72	4.73	0.90
2 nd C	82	290	5350	74.5	5580	11240	5.46	6.27	+0.80	4.66	0.90
2 nd D	82.1	282	5650	74.5	5550	11180	5.43	6.36	+0.92	4.51	0.84

Table 4. Gumry FPF first and second stage Separators Samples (2010).

FPF=Field Process Facilities

In Table 5 and Table 6 predict of the risk of scale buildup inside Heat Exchangers (A, B, C, D), will effect in reducing heat transfer between hot oil and cold oil due to the increase in the pipe wall thickness which caused by calcium carbonate scale layer and that leading to increase energy consumptions and problems of back pressure.

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS I/gm	Conductivity µs	PHs	Hd	IST	RSI	ISA
H.EX.A	78.2	355	5500	74.5	5570	11140	5.51	6.26	+0.75	4.77	1.01
H.EX.B	78	355	5500	74.5	5590	11170	5.51	6.19	+0.67	4.84	1.02
H.EX.C	78.2	355	5350	74.5	5580	11240	5.52	6.27	+0.74	4.78	1.05
H,EX.D	78.3	344	5650	74.5	5550	11180	5.50	6.36	+0.86	4.64	0.97

 Table 5. Gumry Heat Exchangers Samples (2010).

H.EX=Heat Exchanger (A, B, C, D)

 Table 6. Gumry Heat Exchangers Samples (2009).

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Mg/l	Conductivity µs	PHs	Hd	ISI	RSI	ISA
H.EX.A	77.2	355	4500	25	3800	7600	6.07	6.2	+0.12	5.95	2.26
H.EX.B	77	355	4600	25	3650	7300	6.06	6.05	+0.02	6.06	2.23
H.EX.C	77.3	355	4800	30	3740	7720	5.96	6.25	+0.28	5.65	1.999
H,EX.D	77.1	344	4600	35	3680	7120	5.92	6.25	+0.33	5.59	1.91

H.EX=Heat Exchanger (A, B, C, D)

 Table 7. Gumry Crude-Crude Heaters Samples (2009).

Water Sample Source	Temperature °C	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Mg/l	Conductivity µs	PHs	Hd	ISI	RSI	ISA
С.Н.А	81.4	305	4500	25	3800	7600	6.00	6.5	+0.49	5.51	2.1
C.H.B	85	310	4600	25	3650	7300	5.93	6.4	+0.46	5.47	1.97
С.Н.С	80.1	310	4800	30	3700	7720	5.92	6.4	+0.47	5.44	1.90
C.H.D	80	315	4600	35	3680	7120	5.87	6.5	+0.63	5.24	1.84

C.H=crude heater (A, B, C, D)

Water Sample Source	Temperature C ⁰	Pressure kpa	Total alkalinity as CaCO3 mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Ngm	Conductivity µs	PHs	Hd	ISI	RSI	ISA
С.Н.А	81.8	320	5700	74	5580	11170	5.44	6.5	+1.06	4.38	0.85
C.H.B	82	327	5450	74.5	5650	11240	5.45	6.56	+1.10	4.36	0.90
С.Н.С	82	327	5700	74.3	5560	11200	5.43	6.41	+0.97	4.46	0.84
C.H.D	81.6	327	5700	74.5	5700	11630	5.44	6.46	+1.01	4.42	0.85

 Table 8. Gumry Crude-Crude Heaters Samples (2010).

C.H=crude heater (A, B, C, D)

Table 9. Gumry FPF Tanks Samples (2010).

Water Sample Source	Temperature C ^o	Pressure kpa	Total alkalinity as CaCO3 mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	TDS Mg/I	Conductivity µs	PHs	Hd	ISI	RSI	ISA
EX.T.A	73	A.P	5750	70	3300	6610	5.58	6.82	+1.24	4.34	1.12
EX.T.B	74	A.P	5750	70	3300	6600	5.87	6.83	+1.26	4.31	1.09
PWTA	77	A.P	4630	57	3330	6660	5.70	6.46	+0.76	4.94	1.50
PWTB	77	A.P	4630	57	3330	6660	5.7	6.46	+0.76	4.90	1.50

EX.T=Export Tank (A, B), PWT=Produced Water Tank (A, B).

Table 10. Gumry FPF Tanks Samples (2009).

Water Sample Source	Temperature C°	Pressure kpa	Total alkalinity as CaCO ₃ mg/l	Ca ⁺⁺ as CaCO ₃ mg/l	I/gm	Conductivity µs	PHs	Hd	ISI	RSI	ISA
EX.T.A	74.5	A.P	4300	50	3740	7460	5.83	6.85	+1.01	4.82	1.81
EX.T.B	73.5	A.P	4500	70	3550	7002	5.68	6.83	+1.14	4.54	1.48
PWTA	73.3	A.P	4700	60	3850	7720	5.74	6.5	+0.76	4.98	1.56
PWTB	72	A.P	4600	55	3780	7520	5.80	6.5	+0.69	5.11	1.71

EX.T=Export Tank (A, B), PWT=Produced Water Tank (A, B).

In the Table 7 and 8 increase temperature activates the tendency to form calcium carbonate scale in the crude oil heaters due to the decrease of solubility with temperature increase. In the Table 9 and Table 10, pressure drops to atmospheric pressure inside the Tanks would permit to release dissolved acid gases CO_2 from the fluid phases and that reduces the solubility of gases, increase pH of the produced water so all these parameters increase calcium carbonate CaCO₃ Scale to form. LSI increased in the year 2010 is an indication of increasing tendency of calcium carbonate scale forming; see the variations in Figures 1 and 2, high values of LSI in the tanks with low pressure it is good situation for scale forming.



Fig. 1. The trend of LSI 2009.



Fig. 2. The trend of LSI 2010.

In Fig. 3 and Fig. 4 the Ryznar Stability index (**RSI**) predict that all samples which collected in the year 2009 and which in the year 2010 were under threaten of (heavy calcium carbonate (CaCO₃) scale forming). All the samples RSI changed from the range (5 to 6) which means and predict (light scale) in the year 2009 to the range RSI (4 to 5) in the year 2010 which means and predict (heavy scale) except OGM-2 and OGM-3 (2010), expect more complicated problem of scale buildup in the coming years 2011, 2012. If no real treatments or chemical additives done.



Fig. 3. The trend of RSI 2009.



Fig. 4. The trend of RSI 2010.

In Figure 5 and Figure 6, PSI predicts that all samples witch collected in the year 2009 and 2010 were under heavy calcium carbonate (CaCO₃) scale forming, all PSI reading less than (6) which means that the water under tendency of forming calcium carbonate scale.



Fig. 5. The trend of PSI 2009.



Fig. 6. The trend of PSI 2010.

4. CONCLUSIONS

- 1. Many locations in Gumry oil field under threatened by calcium carbonate scale in future:
- 2. Application the special Excel program to calculate Langelier Saturation Index (LSI), Ryznar Stability Index (RSI) and Puckorius Scaling Index (PSI) depend on (Carrier, 1965) equation and can be applied in water industries.
- 3. In order to obtain proper prevention treatment, recommended that to start scale inhibitor immediately inside Gumry FPF to protect from scale accumulation and buildup.

References

- [1] Introduction to water treatment, Vol. II (American Water Work Association], 1984, 118
- [2] *Handbook of Industrial water Conditioning*, 9th edition, Betz. Laboratories Inc., Trevose, USA), 1991, 118.
- [3] Puchorius P. R., Brooke J. M. (1990). A new index for CaCO3 scale prediction in cooling water systems, (paper No. 90) presented at the NACE-corrosion Conf., Las Vegas, USA, 23-27 April 1990.
- [4] Puchorius P. R., Brooke J. M. (1988). Effectively evaluating cooling water programme, (paper No. 17) presented at the NACE-corrosion Conf., St. Louis, USA, 21 - 25 March 1988.
- [5] Langelier W. F., JAWWA 28(10) (1936) 1500-1521.
- [6] Ryznar J. W., JAWWA 36 (1944) 472.
- [7] P. Puckorius, *Get A Better Reading on Scaling Tendency of Cooling Water, Power*, p. 79-81, September, 1983.
- [8] Ferguson R. J. (1992), Developing Scale Inhibitor Models, WATERTECH, Houston, TX.
- [9] Ferguson R. (2011), *Thermodynamics and Kinetics of Cooling Water Treatment*, Association of Water Technologies.
- [10] Ferguson R. J., A Kinetic Model for Calcium Carbonate Scale, CORROSION/84, Paper No. 46, (Houston, TX:NACE INTERNATIONAL 1984).
- [11] Ferguson R. J., Developing Scale Inhibitor Models, WATERTECH, Houston, TX, 1992.12,13
- [12] *Carrier Air Conditioning Company*, 1965. Handbook of Air Conditioning System Design. McGraw-Hill Books. New York.

(Received 02 August 2013; accepted 07 August 2013)